

User Manual

Model: LED Pocket Light
Item: 401679



Included:

- Cold Foot Adapter
- USB Charging Cord
- Magnetic Diffuser
- Warming filter

Operation instruction

Turn On/Off

3. Long press the 'On/Off' button for about 2 seconds to turn on the Pocket Light.
4. Long press the 'On/Off' button for about 2 seconds to turn the Pocket Light back off.

Adjusting the Brightness

1. Long press the + button to increase brightness gradually.
2. Long press the - button to decrease brightness gradually.
3. Short press the + button repeatedly to increase brightness gradually with 6 levels.
4. Short press the - button repeatedly to decrease brightness gradually with 6 levels.

Test the battery power

Short press the 'On/Off' button while the Pocket Light is on. The power indication light will show the current power level.

Charge

Connect the USB charging cable to the Light. The Pocket Light can be charged by mobile power adapter, AC power, or Computer. **Notice: To prevent damage to light, please turn off the light while charging.**

Warnings:

- Never block the ventilation hole by covering it with paper or other materials.
- Never attempt to insert any metal objects into the ventilation holes
- Do not place the Pocket Light near flammable objects.
- Keep LED Pocket Light away from rain and moisture.
- Use a clean, dry, soft cloth to clean the product.
- Contact Smith-Victor for further assistance.

Smith-Victor WARRANTY

Smith-Victor warrants to the first commercial owner to be free from defects in the material and workmanship for a period of one (1) year from the date of purchase and will repair or replace product found to be defective under normal use. Warranty does not cover damage caused by shipment, by product abuse, accident, modification, disassembly or use beyond intended use specified by Smith-Victor.

This warranty is the only warranty made to any person by Smith-Victor and is in lieu of all other expressed or implied warranties. The remedies set forth in this warranty shall be the exclusive remedies available to any person for breach of this warranty. Under no circumstances shall Smith-Victor be liable to any person for incidental or consequential damages, whether arising out of breach of warranty or other contract, negligence, strict liability or other tort or otherwise.

Smith-Victor • Photogenic • Dot Line • Mola
Quantum • Radiopopper • Photoflex • Cool-Lux
Lumedyne • Speedotron • Norman • Logan

Smith-Victor is a division of PromarkBRANDS
1268 Humbracht Circle, Bartlett, IL 60103 U.S.A.
800-348-9862 or 630-830-9200

sales@smithvictor.com | www.smithvictor.com www.promarkbrands.com